

1.2.3 Previous Stern First Ice Class ships have adopted variations on bridge wing orientation and funnel location in order to maximise bridge visibility.

As its name suggests, a vertical lift bridge opens by raising the moving span vertically to improve vertical clearance. It is the only type of movable bridge which does not allow for "infinite" ...

Designs for highway and bridge projects are based on established design controls for the various elements of the project such as width of roadway, side slopes, horizontal and vertical ...

The minimum vertical clearance between the design flood stage and the low member of a bridge is 2 feet. This clearance is necessary to allow the majority of debris to pass without causing ...

Where curves are necessary on road sections near bridge ends, the beginnings and endings of curves should be located so that no portion of the superelevation transition extends onto the bridge.

Excessive movements of bridge foundations, in either vertical or horizontal directions, can lead to a number of problems, including poor ride quality, undesirable appearance, damage to expansion ...

The bridge is raised and lowered by shaft drives acting upon vertical racks on each tower. In this picture, new triple-web sheaves are replacing the severely cracked cast steel sheaves that ...

An RCUT is an at-grade intersection with directional medians such that the minor road traffic must turn right and make a U-turn back to cross or make a left-turn maneuver.

Diverges for left and right turning traffic at interchanges should be combined so that all turning traffic leaves the mainline at one diverge, instead of multiple successive diverges from the mainline.

Bridge drains, piping etc. are in the case of such structures practically no longer accessible and must therefore meet particularly high requirements. Moreover, a large number of ...

Lane-use arrow markings should be used in lanes and turn bays designated for the exclusive use of a turning movement, except where engineering judgment determines that physical ...

A bridge scupper is a vertical opening made within the bridge deck to allow water drainage from the deck. A scupper can also be horizontal hole in the curb since it performs the same ...

Design criteria presented in this chapter apply to new construction and reconstruction projects on arterials and

collectors on the State Highway System.

Web: <https://www.busydoniemiecwaldii.pl>